



SoundStop.co.uk


UK Soundproofing Specialists

Tel- 0208 123 9710




**Genie Clip Installation Instructions
Type LB3**

CEILING INSTALLATION GUIDE




Remove original ceiling plasterboard or lathe and plaster. Once the ceiling has been removed you should now cut to size and friction fit the 100mm AMW60 mineral wool making sure to leave no gaps. If using the LB3 Clip you will be laying the ceiling out in the method shown below. If joist are very closely centered you can miss out a run of joists but normally we recommend furring strips and genie clips on every joist.

WALL OR CEILING LAYOUT



When creating a Genie Clip ceiling you can space the clips out up to up to 1m apart along the furring bars as such this means you can place clips on alternate joists.



- Genie Sound Isolation Clips shall not exceed 1.2m on centre. Along the run of the joist.
- Spacing between the furring channels (hat channel) shall not exceed 600mm. Furring channels are installed perpendicular to the joists.
- Fasten the Sound Isolation Clips to the joist with a fastener approved for a minimum pull out and shear of 50kg we recommend 42-50mm dry wall screws
- Tighten screw until it come into solid contact with the top washer on the Genie Clip.

For best acoustic results **DO NOT OVER TIGHTEN**

- Locate the first row of furring channel within 75 to 150mm of the wall edge and install in a pattern roughly as per drawing below.

- Locate the last of furring channel within 75mm to 150mm of the opposite wall.
- Install all other rows of furring channel ensuring maximum spacing between rows does not exceed 600mm
- Furring channel shall not be cantilevered (over hung with no support) more than 150mm beyond the last Genie clip.
- Snap furring channel into the Genie Clips and make joins between clips with a 150mm overlap. Secure with 13mm wafer head screws.
- For best acoustic results if there is more than one layer of plasterboard, seams should be staggered.
- Caulk around the entire perimeter of the gypsum board filling the whole space with non hardening acoustic caulk. Use acoustic mastic where required. Do not install mastic so that it is 'proud 'of the plasterboard board surface.
- After the mastic has set, tape and finish as usual or skim plaster.